

FUNTRONIX®
SCORE-N-TIME™

**GAMEROOM EDITION
ELECTRONIC SCOREBOARD
WITH REAL TIME CLOCK & DATE**


OPERATING MANUAL
Model SNT-110G

Revision 2011-1-10

Thank you for purchasing a **Funtronix** SCORE-N-TIME™ Gameroom Edition electronic scoreboard. At **Funtronix**, our motto is “Electronic Fun for Everyone”. By offering a line of affordable electronic scoreboards, our goal is to add a little fun to your sports and leisure activities.

 **WARNING:**
CHOKING HAZARD - Small Parts.
Not for children under 3 years.

The contents of the package may contain parts and packing materials that can be hazardous to children under 3 years old. Assembly of these components must to be performed with adult supervision.



While the wall-mount AC adapter is UL approved, the input-side plugs into a standard high-voltage AC outlet. Care should be taken to not make physical contact with the power supply plug area.

Before using your new scoreboard, please read the following precautions. Doing so will reward you with many years of enjoyment with your new Scoreboard. Failure to follow them may cause bodily harm or may damage the scoreboard beyond the terms of the warranty.

1. *DO NOT* expose the scoreboard or keypad to rain or other condensing moisture.
2. *DO NOT* store the scoreboard or keypad in direct sunlight for extended periods of time.
3. *DO NOT* drop or hit the scoreboard, as this may result in injury and/or void the warranty.
4. *DO* read the entire owner's manual so that you will utilize the full potential and versatility of your new scoreboard.

TABLE OF CONTENTS

SECTION	DESCRIPTION	PAGE
1	Scoreboard Setup	4
2	Setting the Real Time Clock and Date Function	4
3	Using Your Scoreboard	5
4	Using the Stopwatch	7
5	Replacing the Keypad Batteries	8
6	Troubleshooting	9
7	Detailed Specifications	9
	Warranty Information	10

PACKAGING CONTENTS

ITEM	QUANTITY	DESCRIPTION
1	1	Gameroom Edition Scoreboard Unit
2	1	Infrared Keypad Remote Controller
3	2	Hanging Hooks
4	3	Keypad Batteries (AAA-Size Alkaline) - Pre-installed
5	1	AC Adapter
6	1	Owner's Manual

SCOREBOARD FEATURES

- Wireless infrared remote control operation
- Large 3 inch clock digits and score digits
- End-of period buzzer
- Displays real time plus month and date or seconds when not used as a scoreboard
- Game clock adjustable from 1 minute to 99 minutes and can also be disabled
- Game clock shows tenth-second resolution when remaining time is less than 1 minute
- Up to 9 periods plus overtime
- Displays team scores up to 199 points
- Stopwatch mode
- Possession arrows for both teams
- Real time clock with month and date

SECTION 1: SCOREBOARD SETUP

1. Insert 3 AAA-size batteries (included) into the keypad. See Section 5 for details regarding the installation of these batteries.
2. Locate a suitable area to hang your scoreboard. Insert the picture hanging nails (included) into the wall. Space the nails twelve inches apart. Be sure the two nails are at an equal height to the floor.
3. Plug the AC adapter into a 120 VAC outlet.
4. Plug the output of the AC adapter into the power connector located on the back of the scoreboard.
5. Hang the scoreboard on the two hanging nails. Make sure the two nails match up to the two hanging rails located on the back of the scoreboard.

SECTION 2: SETTING THE CLOCK, MONTH, AND DATE



1. The scoreboard will power-up in the real time clock mode and the clock display should be blinking "12:00". Aim the remote keypad at the scoreboard and press





the button. This puts the scoreboard in the clock-setting mode. The clock will stop blinking and the colon will stay on.



INFRARED EMITTER - AIM AT SCOREBOARD




2. Adjust the hours with the home  and  buttons.

3. Press the  button to switch between 'AM' and 'PM'. The period display will show an 'A' for 'AM' and 'P' for 'PM'


4. Adjust the minutes with the guest  and  buttons.

5. Adjust the month with the period length  and  buttons located in the lower-left area of the keypad.

6. Adjust the date with the time adjust  and  buttons located in the lower-right area of the keypad.

7. Exit the clock setting mode by pressing the  button.




NOTES:




With the scoreboard displaying the real time and date, pressing the  button will toggle the display between showing the month/date and seconds.



Also, between the hours of 10:00 PM and 6:00 AM the display will dim to reduce light emissions during nighttime hours.



SECTION 3: USING YOUR SCOREBOARD

NOTE: AIM THE KEYPAD REMOTE AT THE SCOREBOARD DISPLAY FOR BEST PERFORMANCE



1. While in the clock/date mode, press the  button on the keypad remote to select the scoreboard mode.
2. If the scoreboard is already being used in the scoreboard mode and a game is in progress, pressing the  button will reset the current game. Successive presses of this button will switch between the various play modes of the scoreboard.
3. The scoreboard includes five modes of play (example displays are shown). Each press of the  button will switch the scoreboard between the five play modes.



 <p>Play Mode 1</p> <p>For activities requiring a game clock.</p> <p>Use for soccer, hockey, and other similarly scored events.</p>	 <p>Play Mode 2</p> <p>For activities not requiring a game clock.</p> <p>Use for non-timed events, such as volleyball and table tennis.</p>	 <p>Play Mode 3</p> <p>Game clock, arrows, and period. No score digits.</p> <p>Use for events where the score isn't being tracked.</p>
--	--	---

 <p>Play Mode 4</p> <p>Game clock only</p> <p>Simple timing function that doesn't require tracking of scores, periods, or use of possession arrows.</p>	 <p>Play Mode 5</p> <p>Stopwatch Mode. Use to time races and other stopwatch-type activities. See Section 4 for details.</p>
---	---


4. If the game clock is enabled, set the length of each period with the period length  and  buttons. The period length can be set for 1 minute to 99 minutes. All periods will start with this time unless it is adjusted again at the start of a game. **The period length can only be adjusted before the start of each period.**



5. Press the  and  buttons to control the game clock.


6. If using the Stopwatch Mode (play mode 3), the  and  buttons will control the stopwatch. The guest score will display the tenths and hundredths digit of the stopwatch. Use the possession arrows to switch between timing each team.


7. For play mode 1 and 2 use home and guest  and  buttons to control the team scores, and the team possession buttons to control the possession arrows.



8. The game horn will sound for approximately 3 seconds at the end of each period.

Pressing the  button will also activate the horn at any time while the game clock is stopped or disabled.

9. During game play, time can be added or subtracted from the game clock (to allow changes from a disputed play). To adjust the game clock's remaining time, first stop the game clock and then press the time adjust  and  buttons in the lower-right area of the keypad to change the game time 1 second at a time (or by tenths of seconds if the remaining time is less than 1 minute).


10. Press the  button when you are ready to advance to the next period.

11. After approximately 10 minutes of non-use, the scoreboard will switch back to the time/date mode. Pressing the  button will re-enable the scoreboard mode with the game data intact.

12. To change the scoreboard back to time/date, press the  button to stop the game clock (if enabled and running), then press and hold the  button for approximately 3 seconds.


NOTE: The keypad remote contains three AAA-size alkaline batteries. Under normal use these batteries will last up to 1 year, depending on usage. If the keypad remote becomes intermittent it may be time to replace the batteries. See Section 5 for details.








SECTION 4: USING THE STOPWATCH

1. With the scoreboard turned on and functioning, repeatedly press the  button until the stopwatch mode is selected. The display will look like the screen shown below:



Stopwatch mode. The main clock display shows the elapsed minutes and seconds, while the guest score display shows the tenths and hundredths of seconds.

Note: The scoreboard will not allow changes to the game mode if the game clock is running. Stop the game clock by pressing the  button.

2. To time a home team race followed by a guest team race (no split times), simply press the  button to start the clock, followed by the  button to stop the clock. You can then change possession to the guest team and repeat the same start and stop function. Toggling between the home and guest possession will show you the time for each team. Press the  button to reset the stopwatch.
3. To time both teams simultaneously (and use the split function), follow these steps:
 - 3.1 Press the  button to start both team's clocks.
 - 3.2 To stop a team's clock, simply press their respective possession button (either the  or  button).
 - 3.3 The first team to have its clock stopped will cause the scoreboard to toggle the stopwatch display to show the opposite team's still-running clock. Press the second team's possession button to stop its team clock.
 - 3.4 Once both team's clocks have been stopped, toggling between the home and guest possessions will display each team's time.
 - 3.5 Press the  button to reset the stopwatch.

SECTION 5: REPLACING THE BATTERIES IN THE KEYPAD REMOTE

1. Remove the four screws using a Philips-head screwdriver. Rotate the screws counter-clockwise to remove.
2. Remove the keypad cover by turning it upside-down and gently taping on the keypad housing towards the bottom-end.
3. Locate the batteries near the bottom-area of the circuit board. Replace all batteries at the same time
4. Insert three new AAA-size alkaline batteries. Observe the polarity of the batteries during installation.
5. Assemble the keypad housing by first inserting the top end of the keypad into the housing, followed by the bottom-end. Turn the screws clockwise until hand-tight. **DO NOT OVERTIGHTEN SCREWS AS THIS WILL DAMAGE THE KEYPAD HOUSING.**



Figure 4.1 Removing the cover screws





Figure 4.2 Open-view of keypad showing the location of the 3 AAA-size batteries.

SECTION 6: TROUBLESHOOTING GUIDE

Symptom: Real Time Clock is not keeping time – colon not blinking.



Solution: Clock is in set-up mode - press the  button on the remote to exit the setup mode.

Symptom: Keypad remote doesn't appear to work or is erratic.

Solution:

1. Make certain you are aiming the remote at the scoreboard when operating.
2. Move the keypad closer to the scoreboard.
3. Reduce the room lighting or other glare from the scoreboard.
4. Replace the batteries in the keypad remote (see Section 5).

Symptom: The game clock is not displayed.

Solution: Press the  button followed by the  button to change the play mode to select the game clock.

SECTION 7: PRODUCT SPECIFICATIONS

(Specifications subject to change without notice.)

FUNCTIONAL SPECIFICATIONS

Operating Modes:

1. Scoreboard with game clock
2. Scoreboard with no game clock
3. Stopwatch
4. Real Time Clock with month and date.

Real Time Clock Accuracy: better than +/- 1 minute per month

Score Digit Range: 0 to 199 points.

Game Clock Range: 1 minute to 99 minutes.

Total Number of Periods: 1 to 9, plus 0 for overtime.

Keypad Operating Range: Up to 25 feet from scoreboard.

ELECTRICAL SPECIFICATIONS

Operating Voltage: +9 volts DC.

Operating Current: 100 mA Nominal, 350 mA maximum with horn sounding.

Keypad Batteries: 3 x AAA alkaline batteries.

MECHANICAL SPECIFICATIONS

Dimensions: 24" X 12" X 2.2".

Weight: approximately 5 pounds.

ENVIRONMENTAL SPECIFICATIONS

Operating Temperature: +10 degrees C to +50 degrees C.

Storage Temperature: 0 degrees C to 80 degrees C.

Humidity: 0 to 95% non-condensing.

Warranty

90 DAY LIMITED WARRANTY

Funtronix LLC warrants the scoreboard against defects in materials and workmanship for ninety (90) days from the date of delivery to the original purchaser. Should any part of the scoreboard, keypad, or AC adapter be proven defective in material or workmanship within this period, such defect(s) will be repaired or replaced at Funtronix's discretion, without charge for parts or labor directly related to the defect(s).

This Warranty extends only to consumers who purchase the scoreboard in the United States or Canada and is non-transferable or assignable.

This Warranty does not apply to:

- Product subjected to abnormal use or conditions, accident, mishandling, neglect, unauthorized alteration, misuse, improper installation or repair or improper storage.
- Product in which the serial number has been removed, altered, or defaced.
- Damage from exposure to moisture, humidity, excessive temperatures, or extreme environmental conditions.
- Damage resulting from connection to, or use of any accessory or other product not approved or authorized by Funtronix LLC.
- Defects in appearance, cosmetic, decorative or structural items such as framing and non-operative parts.
- Product damaged from external causes such as fire, flooding, dirt, sand, weather conditions, battery leakage, theft, or improper usage of any electrical source.

To obtain repairs or replacement within the terms of this Warranty, contact Funtronix to arrange for product(s) to be returned prior to shipping the product. The product should be shipped in its original packaging with proof of Warranty coverage (e.g. dated sales receipt), the consumer's return address, daytime phone number and/or fax number, and complete description of the problem, to Funtronix LLC at the address shown below:

Funtronix LLC
29834 N. Cave Creek Rd
Suite 118-273
Cave Creek, AZ 85331

THE EXTENT OF FUNTRONIX LLC'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL FUNTRONIX LLC'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY THE PURCHASER FOR THE PRODUCT.

ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY MUST BE BROUGHT WITHIN A PERIOD OF 120 DAYS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL FUNTRONIX LLC BE LIABLE FOR ANY SPECIAL CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. FUNTRONIX LLC SHALL NOT BE LIABLE FOR ANY DELAY IN RENDERING SERVICE UNDER THIS WARRANTY OR LOSS OF USE DURING THE TIME THE PRODUCT IS BEING REPAIRED OR REPLACED.

No person or representative is authorized to assume for Funtronix LLC any liability other than expressed herein in connection with the sale of this product.

Some states or provinces do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitation or exclusions may not apply to you. This Warranty gives you specific legal rights and you may have other rights, which vary from state to state or province to province.

Write down your product serial number for your records.

SCOREBOARD SN: _____

Please visit our website for new products and accessories for your scoreboard:

www.funtronixonline.com



Funtronix LLC
29834 N. Cave Creek Rd
Suite 118-273
Cave Creek, AZ 85331
email: sales@funtronixonline.com